



**“GET YOUR KIDS PUMPED  
 TO WASH THEIR HANDS”  
 THE NEW MUSICAL SOAP DISPENSER**

**Problem:**

Proper hand-washing, according to pediatricians, is the best way for kids to stay healthy. Doctors recommend that kids wash their hands for a minimum of twenty seconds to effectively ensure that all of the germs have been killed. However, this can be a difficult task for kids – and adults – of all ages.

**Solution:**

The Musical Soap dispenser is a fun and interactive way for kids to wash their hands for twenty seconds while understanding the length of time necessary for proper hand-washing. Simply dispense the soap, press the button on the base and a musical tune will play for twenty seconds. When the music stops, kids will know that they are finished washing! Fun and simple, kids will enjoy the interactive nature of this product and parents will appreciate the assistance in this important area of personal hygiene.

Case Pack	6
Product Dimensions	3 7/8"L x 3 7/8"W x 9"H
Master Case Dimension	10 5/8" x 10 7/8" x 16 3/4"
Master Case Weight	8.75 lbs.
UPC Code	8-13132-01594-7
Cost/Unit	\$8.95

Distributed By:



5389 E. Provident Dr.  
 Cincinnati, OH 45246  
 866-346-2250